FOR HANDRAILS ON CURVED STAIRCASES

Installation guide

An instruction film is available here. If you have any questions, please contact the factory: +46 (0)513-103 70, info@hlf.se.

Assemble the handrail

1. Begin by laying out the parts.
2. Each part is marked with a number. 1 goes together with 1, and so on. The lowest numbers belong at the bottom of the stair. On the underside of the handrail there is a small mark across the joint, and it is important that these meet, otherwise the joint will not be flush.
3. Screw the parts together. First turn anticlockwise with light pressure until it “clicks” slightly, then turn clockwise until the marks meet in the right place. If they do not, repeat the process.
4. Now lay the handrail on the stair and check that it follows the stair and that the length is correct.

Fit the brackets

> The brackets are fitted so that the handrail ends up at **900 mm** to the top of the handrail. The brackets end up about **800 mm** from the steps to the centre of the wall fixing, measured plumb. The measurement is set by the diameter of the handrail.

5. Now begin by fitting two brackets to the longest part.
6. Then lift the handrail into place, align it and fit the remaining brackets. We recommend not exceeding 1000 mm between brackets. A 1000 mm handrail needs two brackets.
7. Once all the brackets are finally in place, screw the handrail down at every point using the screws supplied.